



Performance Under Pressure

PARTS LIST FOR
GEN-12000-OMHE
GEN-13000-OMSE
(AFTER SERIAL #40020051)

This Parts Listing has been compiled for your benefit. You can be assured your Mi-T-M Generator was constructed and designed with quality and performance in mind using over 25 years experience in the pressure washer business. Each component has been rigorously tested to insure the highest level of acceptance.

The contents of this Parts Listing are based on the latest product information available at the time of publication. Mi-T-M reserves the right to make changes in price, color, materials, equipment, specifications or models at any time without notice.



WARNING

CAUTION SHOULD BE OBSERVED WHEN USING OR REPAIRING THIS UNIT! READ AND FOLLOW THE SAFETY WARNINGS LISTED BELOW BEFORE ATTEMPTING ANY REPAIRS ON THIS GENERATOR!

SAFETY WARNINGS

1. NEVER alter or modify the equipment. Use only genuine Mi-T-M replacement parts for repair of your generator. Failure to do so can cause hazardous operating conditions and will VOID warranty.
2. NEVER make adjustments on machinery while the unit is connected to the engine without first removing the ignition cable from the spark plug. Turning over the machinery by hand during adjustment or cleaning might start the engine and machinery with it, causing serious injury to the operator.
3. Do not operate the unit without all protective covers in place. Know how to stop the generator and turn off circuits quickly. Be thoroughly familiar with controls.
4. Before servicing the unit, turn unit off and allow the unit to cool down. Do not make repairs while the unit is running. Service in a clean, dry, flat area. Block the wheels to prevent the unit from moving. Be especially careful to properly dispose of any flammable materials.

Table of Contents

SPECIFICATIONS.....3

GEN-12000-0MHE & GEN-13000-0MSE (AFTER SERIAL #40020051)4

ENGINE ASSEMBLY (850-0355).....6

ENGINE ASSEMBLY (850-0357).....7

CONTROL BOX ASSEMBLY.....8


WIRE DIAGRAM10

NOTES11

SPECIFICATIONS

MODEL NUMBER	GEN-12000-0MHE	GEN-13000-0MSE
Engine:	20.0 HP Honda	22 HP Subaru
Watts (AC) Rated:	12,000W	13,000W
Watts (AC) Max.:	10,000W	11,500W
Rated Voltage (AC):	120/240V	
Max. Amperage:	100.0A / 50.0A	108.3A / 54.2A
Cont. Amperage:	83.3A / 41.7A	95.8A / 47.9A
Frequency:	60Hz	
Fuel Tank Capacity:	11.5 gal.	
Run Time Hours / Tank of Fuel*:	6.5 hrs.	
Battery for Electric Start:	Part Number #32-0058	
* Rated at Full Load		


GEN-12000-0MHE & GEN-13000-0MSE (AFTER SERIAL #40020051)



GEN-12000_13000-012506-FZ

GEN-12000-0MHE & GEN-13000-0MSE (AFTER SERIAL #40020051)											
REF #	DESCRIPTION	PART #	QTY	REF #	DESCRIPTION	PART #	QTY	REF #	DESCRIPTION	PART #	QTY
1	Bolt	27-0121	4	26	Bolt	27-8881	13	51	Fuel Gauge	12-0184	1
2	Washer	28-0022	8	27	Lockwasher	29-1013	13	52	Plug	24-0009	1
3	Isolation Plate	5-0247A01	1	28	Side Panel	20-0848A01	2	53	Fuel Pick-up	33-0271	1
4	Locknut	30-0157	25	29	Decal- Data Plate	N/A	1	54	Quick Connect Plug	17-0038	1
5	Locknut	30-0159	4	30	Decal- Carb. Emissions	34-1817	1	55	Quick Connect Socket	17-0018	1
6	Engine Assembly - 20 HP Honda (GEN-12000-0MHE)	850-0355	1	31	Frame	5-0245A01	1	56	Clamp Worm	42-0004	2
-	Engine- 22 HP Subaru (GEN-13000-0MSE)	850-0357	1	32	Washer	28-0002	11	57	Battery Retainer	20-0264A01	1
7	Edging *(Three Feet Required)	33-0423	1	33	Locknut	30-0155	4	58	Screw	27-0066	5
8	Heat Shield	20-0851A01	1	34	Push/Pull Toggle Clamp	33-0400	1	59	Battery Box	33-0092	1
9	Washer	28-0003	37	35	Nut	30-0004	1	60	Battery Cable Cover	33-0004	1
10	Lockwasher	29-0007	6	36	Bolt	27-9592	1	61	Terminal Ring	32-0097	3
11	Bolt	27-0067	14	37	Locknut	30-0152	1	62	Cable *(Two Feet Required)	32-0065	2
12	Bolt	27-9527	16	38	Wheel	14-0006	4	63	Terminal Ring	32-0744	1
13	Bolt	27-0117	4	39	Nut	30-0117	4	64	Battery	32-0058	1
14	Generator	32-0886	1	40	Decal- Side Logo	34-1720	2	65	Control Panel	20-0847A01	1
15	Lockwasher	29-0112	1	41	Plug Drain	39-0016	1	66	Decal- Warnings (See 34-9039)	N/A Sep.	1
16	Washer	28-0005	2	42	Fuel Tank	12-0179A01	1	67	Decal- GEN-12000-0MHE	34-1708	1
17	Locknut	30-0161	1	43	Gas Tank Bracket	20-0850A01	2	-	Decal- GEN-13000-0MSE	34-1707	1
18	Vibration Pad	33-0028	6	44	Brake Bracket	20-0849A01	1	68	Hex Nut	30-6001	3
19	Isolation Plate	5-0246A01	1	45	Bolt	27-0015	7	69	Side Panel Bracket	20-0845A01	6
20	Lockwasher	29-0110	1	46	Bolt	27-8807	1	70	Lockwasher	29-0006	3
21	Bolt	27-0168	1	47	Lockwasher	28-1009	4	71	Frame Bracket	20-0846A01	3
22	Edging *(One Foot Required)	33-0433	1	48	Fuel Hose *(Three Feet Required) (GEN-12000-0MHE)	15-0008	1	72	Washer	28-0057	12
23	Conduit Elbow	32-0907	1	-	Fuel Hose *(One Foot Required) (GEN-13000-0MSE)	15-0008	1		Decal Set (Inc. 50, 66)	34-9039	
24	Control Box Assembly (See Exploded Drawing)	N/A Sep.	1	49	Fuel Cap	12-0183	1	*Must Order in One Foot Lengths			
25	Spiral Wrap *(One Foot Required)	33-0114	1	50	Decal- Caution: Risk of Fire (See 34-9039)	N/A Sep.	1				

ENGINE ASSEMBLY (850-0355)




850-0355-090605-KZ

ENGINE ASSEMBLY (850-0355)			
REF #	DESCRIPTION	PART #	QTY
1	Engine- 20HP Honda	1-0157	1
2	Muffler	45-0109	1
3	Spark Arrestor	45-0110	1
	Engine Assembly (Includes 1-3)	850-0355	

850-0355-090605-KZ

ENGINE ASSEMBLY (850-0357)




850-0357-011806-PO

ENGINE ASSEMBLY (850-0357)			
REF #	DESCRIPTION	PART #	QTY
1	Key Switch	32-0917	1
2	Bolt	27-8881	3
3	Lockwasher	29-1013	3
4	Decal- On/Off/Start (See 34-9039)	N/A Sep.	1
5	Switch Panel	20-0865	1
6	Switch Box	20-0866	1
7	Engine- 22HP Subaru	1-0158	1
8	Muffler Assembly	45-0118	1
	Engine Assembly (Includes 1-8)	850-0357	
	Decal Set (Inc. 4)	34-9039	

850-0357-011806-PO

CONTROL BOX ASSEMBLY




GEN-12000_13000 CONTROL BOX ASSY-092705-KZ


CONTROL BOX ASSEMBLY

REF #	DESCRIPTION	PART #	QTY	REF #	DESCRIPTION	PART #	QTY
1	Decal- Operations (See 34-9039)	N/A Sep.	1	19	Bolt	27-0740	2
2	Bolt	27-8942	4	20	Toggle Breaker- SP 20A	32-0834	3
3	Power Block Adder	32-0912	1	21	Control Panel	20-0837A01	1
4	Power Block 3-Pole	32-0905	1	22	Locknut	30-0152	14
5	Locknut	32-0587	1	23	Toggle Breaker- SP 30A	32-0836	1
6	Electric Box Cover	20-0836A01	1	24	Toggle Breaker- DP 30A	32-0837	1
7	Strain Relief	32-0586	1	25	Circuit Breaker Toggle- DP 50A	32-0902	1
8	Electric Box Assembly	20-0835A01	1	26	Bolt	27-9574	16
9	Conduit Elbow	32-0907	1	27	Receptacle- GFCI Duplex 20A	32-0830	3
10	Conduit Flex *(Two Feet Required)	32-0908	1	28	Receptacle- L14-50	32-0904	1
11	Locknut	30-0155	1	29	Receptacle- L14-30	32-0831	1
12	Washer	28-0002	2	30	Receptacle- L5-30	32-0832	1
13	Bolt	27-8881	28	31	Volt Meter	32-0838	1
14	Lockwasher	29-1013	42	32	Hour Meter	32-0668	1
15	Capacitor Clamp Bracket	20-0797A01	2	33	Rocker Switch	32-0626	1
16	Capacitor	32-0846	2	34	Decal- Control Panel (See 34-9039)	N/A Sep.	1
17	Bolt	27-0022	1		Decal Set (Inc. 34)	34-9039	
18	Idle Down Board	32-0896	1				

WIRE DIAGRAM



GEN-12000_13000 WIRE DIAGRAM-092705-KZ



NOTES



Call AAA Rent-All at 225-291-1356 for assistance ordering parts

Manufactured by Mi-T-M
8650 Enterprise Drive, Peosta IA 52068
563-556-7484/ Fax 563-556-1235