




3 601 M23 210

Stand | 15-02
Issue | 15-03-05

Fig. / Abb. 2


Änderungen vorbehalten
Modifications reserved
Modifications réservées
Salvo modificaciones



3 601 M23 210

Stand | 13-02
Issue | 17-02-14

Fig. /Abb. 3




Änderungen vorbehalten
Modifications reserved
Modifications réservées
Salvo modificaciones



3 601 M23 210

Stand | 13-02
Issue | 16-06-08

Fig. /Abb. 4



Änderungen vorbehalten
Modifications reserved
Modifications réservées
Salvo modificaciones



Pos.	Part Number	Description	Pos.	Part Number	Description
2	1 609 B04 897	Field	95	1 609 B04 820	Chip Deflector
4	2 610 950 336	Switch	96	1 609 B04 821	Chip Deflector
5	1 609 B04 861	Power supply cord	97	1 609 B04 816	Pivot Pin
7	1 619 P03 808	Cable Clip	102	1 609 B04 822	Gasket
8	1 609 B04 945	Nameplate	103	1 609 B04 825	Cable Clip
9	1 609 B04 948	Manufacturer's nameplate	104	1 609 B04 826	Wear Plate
13	1 609 B00 597	Bearing	105	1 609 B04 827	Cable Clip
32	1 609 B04 702	Sliding Plate	106	1 609 B04 828	Carrying Handle
33	1 609 B04 703	Detent plate	107	1 609 B04 829	Screw
34	1 609 B04 704	Scale	109	1 609 B04 831	Torsion Spring
38	1 609 B04 991	Mitre Fence	111	1 609 B04 832	Screw
39	1 609 B04 992	Mitre Fence	115	1 609 B04 836	Screw
41	1 609 B04 711	Mitre Fence	116	1 609 B04 837	Torsion Spring
42	1 609 B04 712	Mitre Fence	117	1 609 B04 838	Compression Spring
43	1 609 B04 715	Knob	122	1 609 B04 843	End cap
44	1 609 B04 721	Table	123	1 609 B04 844	Plate
45	1 609 B04 722	Shaft	126	1 609 B04 847	Dust Extraction
47	1 609 B04 725	Knob	127	1 609 B04 848	Support bracket
48	1 609 B04 726	Rod	132	1 609 B04 857	Wire
49	1 609 B04 727	Cover	141	1 609 B04 875	Linkage
51	1 609 B04 728	Supporting foot	142	1 609 B04 876	Shoulder Screw
52	1 609 B04 743	Detent	143	1 609 B04 892	Intermediate Flange
53	1 609 B04 744	Shoulder Screw	144	1 609 B04 901	End cap
54	1 609 B04 745	Contact strap	145	1 609 B04 904	Baffle
55	1 609 B04 746	Ball	146	1 609 B04 911	Screw
56	1 609 B04 747	Detent	148	1 609 B04 915	Wire
57	1 609 B04 748	Detent	149	1 609 B04 916	Wire
58	1 609 B04 749	Contact strap	151	1 609 B04 920	Wire
59	1 609 B04 750	Leaf Spring	152	1 609 B04 918	Wire
61	1 609 B04 751	Pointer	154	1 609 B04 921	Sleeve
62	1 609 B04 752	Scale	155	1 609 B04 922	Sleeve
63	1 609 B04 754	Sliding Plate	156	1 609 B04 923	Clip
64	1 609 B04 755	Cover	158	1 609 B04 954	Label
65	1 609 B04 756	Contact strap	159	1 609 B04 955	Label
66	1 609 B04 758	Leaf Spring	162	1 609 B04 952	Label
67	1 609 B04 761	Post	163	1 609 B04 953	Label
68	1 609 B04 773	Pointer	164	1 609 B04 956	Label
69	1 609 B04 774	Pointer	165	1 609 B04 957	Label
71	1 609 B04 775	Bearing	166	1 609 B04 958	Label
72	1 609 B04 776	Wear Plate	167	1 609 B05 245	Warning Label
73	1 609 B04 778	Plate	168	1 609 B04 233	Warning Label
74	1 609 B04 780	Felt	169	1 609 B04 938	Label
75	1 609 B04 781	Knob	171	1 609 B04 939	Label
76	1 609 BP7 343	Contact strap	172	1 609 B04 940	Label
77	1 609 B04 794	Locking Lever	173	1 609 B04 782	Plate
78	1 609 B04 795	Lever Shaft	174	1 609 B04 783	Shoulder Screw
79	1 609 B04 798	Cover	175	1 609 B04 823	Safety Guard
81	1 609 B04 801	Arm	176	1 609 B04 824	Torsion Spring
83	1 609 B04 803	Belt Cover	183	1 609 B04 757	Washer
84	1 609 B04 804	Transmission Shaft	186	1 609 B04 762	Leaf Spring
85	1 609 B04 805	Pulley	187	1 609 B04 959	Label
86	1 609 B04 806	Sprocket	201	1 609 B00 207	Belt
87	1 609 B04 807	Washer	202	1 609 B00 211	Flange Bolt
88	1 609 B04 808	Chain	203	1 609 B00 213	Flange Bolt
89	1 609 B04 809	Output Shaft	204	1 609 B00 223	Screw
91	1 609 B04 810	Plate	205	1 609 B00 225	Nut
92	1 609 B04 811	Spindle	206	1 609 B01 431	Supporting foot
93	1 609 B04 812	Cover	207	1 609 B00 256	Wrench Socket



Pos.	Part Number	Description	Pos.	Part Number	Description
208	1 609 B00 305	Bolt	295	1 609 B01 660	Screw
209	1 609 B00 350	Knob	296	1 609 B01 664	Screw
212	1 609 B00 370	Shaft	297	1 609 B01 668	Washer
213	1 609 B00 382	Knob	298	1 609 B01 665	Screw
214	1 609 B00 390	Button	299	1 609 B01 693	Screw
215	1 609 B00 417	Compression Spring	300	1 609 B01 992	End Clip
216	1 609 B00 418	Sleeve	304	1 609 B00 653	Screw
218	1 609 B00 449	Bushing	305	1 609 B01 696	Washer
222	1 609 B00 454	Screw	309	1 609 B00 208	Flange
224	1 609 B00 457	Washer	310	1 609 B00 210	Flange
225	1 609 B00 458	Quick-Lock	317	1 609 B02 467	Bumper
227	1 609 B00 478	Brush-Cover	325	1 609 B03 179	Screw
228	1 609 B00 480	Rubber Bushing	326	1 609 B03 722	Screw
229	1 609 B00 483	Bearing Plate	327	1 609 B03 733	Control Lever
235	1 609 B00 533	Rubber Bushing	329	1 609 B03 741	Lock Plate
237	1 609 B00 592	Key	330	1 609 B03 742	Adjusting bolt
238	1 609 B00 593	Key	331	1 609 B03 753	Slide Stop
239	1 609 B00 596	Bearing	332	1 609 B03 770	Friction Plate
241	1 609 B00 601	O-Ring	333	1 609 B03 776	Stop bolt
242	1 609 B00 602	Bolt	334	1 609 B04 086	Screw
243	1 609 B00 603	Lock Nut	335	1 609 B04 227	Adjusting Nut
244	1 609 B00 605	Lock Nut	336	1 609 BP7 059	Connection Block
245	1 609 B00 617	Set screw	338	1 609 BP7 124	Roller
246	1 609 B00 627	Screw	339	1 609 B00 622	Rivet
247	1 609 B00 630	Screw	351	1 609 B01 463	Shoulder Screw
248	1 609 B00 633	Screw	352	1 609 B04 865	Button
249	1 609 B00 636	Tapping Screw	354	1 609 B01 529	Linkage
251	1 609 B00 637	Tapping Screw	355	1 609 B01 530	Compression Spring
252	1 609 B00 641	Retaining ring	801	1 609 B05 013	Housing Assembly
253	1 609 B00 643	Retaining ring	803	1 609 B05 027	Armature assembly
254	1 609 B00 644	Retaining ring	810	1 609 B02 314	Carbon-Brush Set
255	1 609 B00 649	Screw	812	1 609 B05 016	Tensioning Bracket
256	1 609 B00 650	Screw	814	1 609 B02 316	Bearing
257	1 609 B00 652	Screw	818	1 609 B05 020	Sprocket
258	1 609 B00 654	Screw	819	1 609 B05 021	Carrier
259	1 609 B00 658	Spring Washer	824	1 609 B05 009	Clamp
262	1 609 B00 662	Washer	824/232	1 609 B00 523	Rubber Pad
264	1 609 B00 665	Washer	825	1 609 B05 018	Dust Extraction
265	1 609 B00 667	Washer	829	1 609 B05 011	Switch Handle
266	1 609 B00 669	Washer	831	1 609 B05 022	Base Unit
268	1 609 B00 674	Washer	835	1 609 B05 023	Extension Stand
269	1 609 B00 675	Washer	836	1 609 B05 024	Extension Stand
271	1 609 B00 678	Screw	837	1 609 B05 029	Lower guard
273	1 609 B00 690	Retaining ring	846	1 609 B05 028	Plate
275	1 609 B00 861	Knob	856	1 609 B05 010	Dust Bag
277	1 609 B01 041	Hex Nut	882	1 609 B05 026	Chain Cover
278	1 609 B04 799	Screw			
279	1 609 B01 194	Tapping Screw			
281	1 609 B01 356	Cyl Head tapping screw			
282	1 609 B01 388	Screw			
283	1 609 B04 869	Strain-Relief Clamp			
284	1 609 B01 462	Shoulder Screw			
285	1 609 B01 512	Cable Clip			
287	1 609 B01 531	Trigger			
288	1 609 B01 533	Cord guard			
289	1 609 B01 538	Cable Tape			
292	1 609 B01 599	Control Screw			
293	1 609 B01 605	Bushing			